

產品

Embla RA 16



Embla RA 16 自動調節剝線鉗
, 4-16 mm²/AWG 12-5, O型刀片

Pistol grip provides stress free comfort, particularly when operating parallel to a table or workbench.

Tool-less interchangeable stripping cassettes allow a wide and diverse stripping capacity

Widest stripping capacity of any tool of its type

Durable, integrated wire cutting capability

Cutting capacity: Flexible wires, 10 mm²/8 AWG.
Rigid wires, 1.5 mm² /16 AWG

Fine adjustability for thin or thick insulation, without damage to wire conductors

At the end of the stripping function, the stripping blades open and remain open to facilitate easy and snag free wire removal from the tool

Ergonomic: strong, durable, and comfortable ergonomic design

Replacement stripping cassettes and cutting blades available.

可靠: Frame and mechanism life span exceeds 150,000 cycles (tested with 1.5 mm²/AWG 16 PVC cable).

資訊

長: 144 mm/5.67"

寬: 23 mm/0.9"

高: 168 mm/6.61"

重量: 165 gr/0.37 lb

電線尺寸: 4-16 mm² / AWG 12-5

剝線尺寸 mm/mm²:

3-18 mm/可調節

剝線尺寸英尺/AWG: 0.12-0.71"/可調節

電線: PVC

種類: 自動調節剝線鉗 · 用於PVC絕緣中的電氣安裝和設備電線 ·

壽命週期: 150,000 (1.5 mm²/AWG 16 PVC 電線測試)

刀片組 (灰, 紅, 藍) 亦可單獨項目提供

