

產品

# EMBLA VBC



Embla VBC is a self adjusting stripping and cutting tool, 0.1-4 mm<sup>2</sup>/AWG 28-12, V-blade.

- Tool-less interchangeable stripping cassettes allow a wide and diverse stripping capacity
- Widest stripping capacity of any tool of its type
- Durable, integrated wire cutting capability
- Cutting capacity: Flexible wires, 10 mm<sup>2</sup>/8 AWG. Rigid wires, 1.5 mm<sup>2</sup> /16 AWG
- Fine adjustability for thin or thick insulation, without damage to wire conductors
- At the end of the stripping function, the stripping blades open and remain open to facilitate easy and snag free wire removal from the tool
- Ergonomic: strong, durable, and comfortable ergonomic design
- Replacement stripping cassettes and cutting blades available.
- Reliable: Frame and mechanism life span exceeds 150,000 cycles (tested with 1.5 mm<sup>2</sup>//AWG 16 PVC cable).

#### 資訊

長: 191 mm/7.52"

寬: 20 mm/0.79"

高: 90 mm/3.54"

重量: 136 gr/0.3 lb

電線尺寸: 0.1-4 mm<sup>2</sup> / AWG 28-12

剝線尺寸 mm/mm<sup>2</sup>:

3-18 mm/可調節

剝線尺寸英尺/AWG: 0.12-0.71"/可

調節

電線: PVC / PTFE 與類似

種類: 用於PVC和PTFE絕緣的電氣安

裝和設備電線的自動調節剝線鉗。V

型刀片刀具·使硬質絕緣更容易剝

離。

壽命週期: 150,000 (1.5 mm<sup>2</sup>/AWG

16 PVC 電線測試)

刀片組 (灰, 紅, 藍) 亦可單獨項目提供

